COUNTER W/ FIRE DOORS

FLOOR 1 CALL 911 FIRE ALARM WILL SOUND AS CHIRPING ELECTRICAL HORN, STROBE LIGHT WILL FLASH. PERSONS WITH DISABILITIES

CALL 911, REPORTYOUR LOCATION,PROCEED TO THENEAREST EXIT OR EXITSTAIRWELL ANDAWAIT ASSISTANCE. ALARM PULL STATIONEMERGENCY EGR

IN CASE OF FIRE USE STAIRWAYS LAST REVISION: OCTOBER 2016 FIRE POLICE IN CASE OF FIRE, PULL FIRE ALARM, USE EXIT STAIRS, CLOSE ALL WINDOWS AND DOORS, DO NOT USE ELEVATOR.STAIRSMBS COMPLEX, FS741EVACUATION PLANFOR REVISIONS OR COPIES CONTACT DDC DRAFTING AT UAF-DDC-CADD@ALASKA.EDU